

## Instructions for Tuning your receiver to the Optus D2 Satellite

### ***Humax F2-1002***

Before you begin, identify the following buttons on the remote control for the satellite receiver:  
**Menu, exit, back, OK, the up-down and left-right buttons;**

Switch on the satellite receiver and TV as you normally would to watch one of the channels:-

#### **Notes**

- When you 'select' an item on the on main-menu it will be offset to the right of the other items
- When you 'select' an item on other menus it will be highlighted with a yellow border.

#### ***To delete all existing channels:-***

1. Press the **menu** button.
2. Use the **up** or **down** buttons to select **Edit\_Channels** and press **OK**.
3. Select **Edit\_Channel\_Lists** and press **OK**
4. The receiver will request a password. Enter **0000**.
5. Select **Group** and press **OK**. Select **Optus\_B3** and press **OK**.
6. Select **Select\_All** and press **OK**. All channels will be highlighted.
7. Select **Delete** and press **OK**.
8. Press **back** to exit this menu and the receiver will display a pop-up message, "Do you want to save all the changes?" Select **Yes** and press **OK**.
9. Press **back** repeatedly to exit all menus.

#### ***To scan in the channels:-***

1. Press the **menu** button.
2. Use the **up** or **down** buttons to select **Installation** and press **OK**.
3. The receiver will request a password. Enter **0000**.
4. Select **Manual\_Search** and press **OK**.
5. Select **Satellite** and press **OK**. Select **Optus\_B3** and press **OK**.
6. Select **Transponder** and press **OK**.
7. Scroll down to the bottom and select **User\_Define**.
8. Select **Frequency** and press **OK**. Enter **12706** and press **OK**.
9. Select **Polarity** and press **OK**. Select **Auto** and press **OK**.
10. Select **Symbol Rate** and press **OK**. Scroll down to **User\_Define** and press **OK**. Enter **22500** and press **OK**.
11. Select **FEC** and press **OK**. Select **Auto** and press **OK**.
12. Select **DONE** and press **OK**.
13. Select **Network\_Search** and press **OK** to choose **Enable**.
14. Select **Search\_Type** and press **OK**. Select **FTA** and press **OK**.
15. Select **Channel\_Type** and press **OK**. Select **All** and press **OK**.
16. Select **SEARCH** and press **OK**.
17. The receiver will take some time to search through all the available channels, which will be progressively displayed as they are found.
18. On the right hand bottom corner, select **SAVE** and press **OK**.
19. Press **back** repeatedly to exit all menus.

### ***To re-organize the channels:-***

1. Press the **menu** button.
  2. Use the **up** or **down** buttons to select **Edit\_Channels** and press **OK**.
  3. The receiver will request a password. Enter **0000**.
  4. Select **Edit\_Channel\_Lists** and press **OK**
  5. Select **Groups** and press **OK**. Select **TV** and press **OK**.
  6. On the left hand side, highlight one or many channels by pressing the **OK** button.
  7. On the right hand side, select **MOVE** and press **OK**.
  8. Press the **up** and **down** buttons to move the selected channels to the correct position. Press **OK** to place channels.
  9. Repeat steps 7 and 8 until all channels are in order.
  10. Press **back** to exit this menu and the receiver will display a pop-up message, "Do you want to save all the changes?" Select **Yes** and press **OK**.
  11. If you use radio channels, repeat steps 5 to 9, choosing **Radio** instead of **TV** in step 5.
  12. Press **back** repeatedly to exit all menus.
- 

If you have another brand of satellite receiver, these are the new parameters for Optus D2 that will need to be entered in to your satellite receiver.

Freq: 12,706 GHz  
Symbol rate: 22,500  
Pol: Vertical  
FEC: 3/4  
Network Search: Enable.